



Parts List for DCF887D2-B3 Type 1

Item Number	Part Number	Description	Qty Required
1	N413423	HOUSING ASSEMBLY	1
2	N442102	MOTOR & SWITCH ASSY.	1
3	N112877	RING GEAR	1
4	N075339	O-RING	1
5	N439270	MECHANISM ASSY	1
6	N439271	NOSE CONE ASSY.	1
7	642883-00	WASHER - URETHANE	1
8	N439275	ANVIL ASSY.	1
9	N424434	LIGHT RING ASSEMBLY	1
11	N399342	FWD/REV BUTTON	1
12	N437890	SPRING	1
13	N089668	STEEL BALL	1
14	N019351	COMPRESSION SPRING	1
15	N415593	SLEEVE	1
16	N453417	PLAIN WASHER	1
17	N421245	RETAINING RING	1
18	682211-00	SCREW PLASTITE	8
19	N268241	BELT HOOK KIT	1
20	N042665	MACHINE SCREW	1
24	N424032	HOG RING	1
25	N046201	SPEED SELECTOR	1
26	N087259	DETENT SPRING	1
29	N439105	WARNING LABEL	1
30	N458080	RATING LABEL	1
31	N439112	LABEL	1
800	N017298	GREASE	1
800	286436-00	GREASE, 500GRAMS	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for DCF887D2-B3 Type 1

Item Number	Part Number	Description	Qty Required
836	233945-00	SERVICE TOOL	1
861	N197072	KITBOX	1
866	DCB203-B3	BATTERY PACK	2
871	N406055	CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.